
1 Set Button
2 Advance Buttton
3 Battey Container
Alarm On
AL Alarm Set
Chime ON
DISPLAY
Time
11:16
Alarm Time
-3sec
8:30
Date (MM DD)
3 29
Second
:48
Push button(1)to reset the second figure to zero.
SETTING
Time
11:16
Alarm&Chime off
8:30
Alarm On
Alarm&Chime On
Chime On
AL.ON/OFF
Alarm Hour Set
Adjust Figure
Alarm Minute Set
Adj
AL.TIME
If there is any adjustment on the alarm time,it will return to the time display mode.
Adj
Date Set
29
Month Set
3
DATE
Hour Set
11: P
Minute Set
:16
Time Hold
11:16
TIME
*12/24 hour cycle option appear alter nately on every 24 hrs.
If no adjustment on minute,it will return to the time.

Don't explore to UV light directly